


MAY 21-1915
 REVISED
 3-15-22-F.M.
 7-10-22 F.M.



- | | | | | | |
|---------|-------------------------------------|--------|--|-----------------|----------------------------------|
| T-472-B | Nut (vibrator bolt) | T-6743 | Spring (vibrator cushion) | T-6777 | Tinfoil (condenser) |
| 5845 | Unit (coil) assembly | 6744 | Nail (for side of unit) | 6778 | Tape (primary wire fastener) |
| 6698 | Hydrolene .260 | 6745 | Wire (core) for primary | 6779 | Paper (binding for condenser) |
| 6699 | Paraffin | 6747 | Insulator (glass) | 6780 | Sticker (secondary coil) |
| 6700 | Cover | 6749 | Washer (vibrator adjusting bolt) | 6781 | Paper (glassine for condenser) |
| 6702 | Bridge (assembly) | 6751 | Paraffin (crude) | 6782 | Screw (lower bridge adjusting) |
| 6704 | Top (coil unit box) | 6752 | Paper (primary) | 6783 | Wedge (coil unit) |
| 6706 | Bottom (coil unit box) | 6753 | Compound (impregnating) | 6784 | Block (coil unit L) |
| 6707 | Back (coil unit box) | 6754 | Nut (vibrator adjusting bolt lock) | 6785 | Screw (armature to lower bridge) |
| 6708 | Side (coil unit box) rear | 6755 | Tube (primary) | 6786 | Washer (contact) |
| 6711 | Side (coil unit box) front | 6757-B | Vibrator adjusting bolt washer upper. | 6790 | Rivet (contact washer) |
| 6718 | Condenser (spark coil assembly) | 6758 | Bridge (vibrator upper) | 6793 | Box (coil unit) |
| 6721 | Coil (primary assembly) | 6759 | Armature (vibrator) | 6794 | Coil (secondary) |
| 6722 | Winding (secondary assembly) | 6761 | Spacer (condenser & secondary) | 6795 | Wire (primary) |
| 6723 | Rosin | 6767 | Vibrator cushion spring rivet | 6797 | Armature (vibrator assembly) |
| 6725 | Wax (carnuda) | 6768 | Collar (vibrator bolt) | 6798 | Spring (vibrator cushion assy) |
| 6726 | Spring (vibrator adjusting bolt) | 6769 | Rivet (vibrator cushion spring spacer) | 6799 | Point (contact) |
| 6727 | Bolt (vibrator long) | 6770 | Bridge (vibrator lower) | 8881 | Wedge (condenser) |
| 6728 | Bolt (vibrator adjusting) | 6772 | Nut (vibrator bolt) | 8818 | Spacer (condenser & secondary) |
| 6733 | Bolt (vibrator short) | 6773 | Wire (vibrator bolt to condenser) | 8882 | Bolt (vibrator assembly) |
| 6734 | Paste | 6774 | Terminal (condenser) | 8883 | Bolt (vibrator assembly) |
| 6736 | Bridge (lower) | 6775 | Glue (colon) | | |
| 6737 | Vibrator and lower bridge assembly. | 6776 | Wire (vibrator bolt to contact-washer) | | |

SK
 2202

SKETCH SHOWING UNIT COMPLETE ALSO NUMBERS & NAMES OF PARTS

SK-2202